## SpaceBuilder Specification Worksheet







The GLZUM SpaceBuilder™ system is an ideal wireless lighting control system for any space, new construction or retrofit. It provides dimming, switching, motion sensing, keypads, and plug load control. Each GLZUM space can support up to 32 Zūm™ devices.

SpaceBuilder allows you to define your space and how it works at the time of design. Use this sheet to select your options and needs for the lighting control system. The GLZUM system is unique in that you can set up from the Crestron Zūm app and operate from keypads, sensors or time clock control. All SpaceBuilder GLZUM solutions are wirelessly pre-paired at the factory! When it arrives on-site it is ready to go!

# **System Components**

### Dimmers and Switches

Wall box or Jbox dimmers and switching devices are available in Phase control, Universal phase, 0-10V and switching options. Any combination of these devices can be made and added to each GLZUM system.

### Occupancy or Vacancy Sensors

Up to 8 wireless PIR (passive infrared) battery-powered occupancy sensors can be added to each GLZUM space. Occupancy sensors count as part of the total wireless device count of 32 max per space. SIM and Steinel sensor options allow for even greater installation and coverage pattern flexibility.

### **Daylight Sensor**

Any GLZUM space can support one wireless dual technology daylight sensor with auto calibration. The Daylight sensor devices count as part of the total wireless device count of 32 max per space.

### Control

Any GLZUM space can be controlled from either line voltage or battery powered wireless keypads, as well as from sensors (automation) and time clock management (scheduling events via software/programming).

# **Options**

### Plug Load Control

Any GLZUM system can be expanded to include plug load control. Plug load control devices count as part of the total wireless device count of 32 max per space.

### **HVAC Integration**

Any GLZUM system can integrate with HVAC by using an optional ZUM-CC and providing a contact closure interface to the HVAC system in sync with the occupancy or vacancy sensors. The ZUM-CC counts as part of the total wireless device count of 32 max per space.

### **AV Integration**

A wireless AV bridge can be added to allow any AV system to control the lights via a serial RS-232 connection.

### Networking


Any Crestron SpaceBuilder system can be networked\* to provide centralized monitoring, management and master control. This includes integration of BMS and reporting, alerts, maintenance, and global time clock management.

\*Networking requires additional equipment.

GLZUMSW	LVDIM	DELV	_JB0X_SW	JBOX_LV5A-	JB0X_	LV16A	DIMU	PL	_AKP	_BKP	_AKP_BATT-
BKP_BATT	_CKP_BATT	_DKP_BATT									PS
Date:	Project:_										
Quantity:	Space Na	ame:									
Space Number(s):											

# SpaceBuilder Specification Worksheet | GLZUM System






©2019 Crestron Electronics, Inc. WS\_10\_09\_2019



### GLZUM SpaceBuilder Schematic Riser




GLZUM	SW	LV	DIM	DELV	_JB0X_S	SW	_JBOX_LV5	A	JBOX_LV16	ADIM	UPL-	AKP-	BKP-	A	KP_BATT
BKP_	BATT	_CKP_B	BATT	_DKP_BATT											_PS
Date:			Project:_												

Date: Project: Quantity: Space Name: Space Number(s):



### GLZUM SpaceBuilder Sequence of Operations

KEYPAD TYPE A Office, Restroom, Storage/Utility Room, Corridor, Basic Classroom



### Button 1 Functionality: ON


- > Turn all lights on and enable daylight harvesting
- > If daylight sensor is not present, lights will turn on to 100%
- > Press and hold will raise all dimmable lighting

### Button 2 Functionality: OFF

- > Turn all lights off to 0% and disable daylight harvesting
- > Press and hold will lower all dimmable lighting

### KEYPAD TYPE B

Office, Conference Room, Classroom, Library



### Button 1 Functionality: ON

- > Turn all lights on and enable daylight harvesting
- > If daylight sensor is not present, lights will turn on to 100%
- > Press and hold will raise all dimmable lighting

### Button 2 Functionality: SCENE 2

> Recalls scene 1 settings with feedback

### Button 3 Functionality: SCENE 3


> Recalls scene 2 settings with feedback

### Button 4 Functionality: OFF

- > Turn all lights off to 0% and disable daylight harvesting
- > Press and hold will lower all dimmable lighting

### KEYPAD TYPE C

Office, Conference Room, Classroom, Library



### Button 1 Functionality: ON

- > Turn all lights on and enable daylight harvesting
- > If daylight sensor is not present, lights will turn on to 100%
- > Press and hold will raise all dimmable lighting

### Button 2 Functionality: SCENE 2

> Recalls scene 1 settings with feedback

### Button 3 Functionality: SCENE 3

> Recalls scene 2 settings with feedback

### Button 4 Functionality: OFF

> Turn all lights off to 0% and disable daylight harvesting

### Button **A** Functionality:

> Dim lights up

### Button **▼** Functionality:

> Dim lights down

### KEYPAD TYPE D

### Typical Applications

# ON SCENE 2 OFF

### Button 1 Functionality: ON

- > Turn all lights on and enable daylight harvesting
- > If daylight sensor is not present, lights will turn on to 100%
- > Press and hold will raise all dimmable lighting

### Button 2 Functionality: SCENE 2

> Recalls scene 1 settings with feedback

### Button 3 Functionality: SENSOR DISABLE

Disables motion sensors for 2 hours

### Button 4 Functionality: OFF

> Turn all lights off to 0% and disable daylight harvesting

### Button **A** Functionality:


> Dim lights up

### Button ▼ Functionality:

> Dim lights down

GLZUM	SW	LVI	DIMI	DELV	JROX_S	5W	JB0X_F	.V5A	_JBOX_L/	/16Al	JIMUF	'L <i>l</i>	4KP	BKP	_akp_	BALL
BKP_E	BATT	_CKP_BAT	ΓTDŀ	KP_BATT-											PS	

Date:	Project:
Quantity:	Space Name:
Space Number(s):	'



# Zūm App

Adding a ZUMMESH-NETBRIDGE to a Zūm MESH space gives you BLE (Bluetooth® Low Energy) connectivity to the Zūm App. The Zūm App allows for super fast access to the parameters of the zones, keypads, and sensors within the Zūm MESH space. And because it's wireless, there's no need to remove a ceiling tile or get on a ladder.

### Features include:

- > Naming the Zūm MESH space and giving it a unique PIN number
- > Checking battery life on all batteries
- > Setting scenes with the use of zone controlled sliders in real-time
- > Adjusting dimming curves for each zone including high and low end trim
- > Daylight and motion sensor adjustment





The Zum App is available on both iOS® and Android™

GLZUMSW	_LVDII	VIDELV	JBOX_SW	JB0X_LV5A	JB0X_LV16A	DIMU	PL	AKP	BKP	AKP_BATT-
BKP_BATT	CKP_BATT-	DKP_BAT	Т							PS
Date:		ject:				-				

Space Number(s): \_\_\_\_\_\_\_ ©2019 Crestron Electronics, Inc. WS\_10\_09\_2019



# Zūm Floor Hub

The Crestron ZUM-FLOOR-HUB networks up to 200 Zūm rooms or spaces, providing a single point of control for the commercial lighting system. The hub features an astronomical time clock for scheduling lighting events, centralized management and control for each space or across all the spaces at once, and real-time room status updates. The Zūm Hub forms the core of any modern networked commercial lighting installation, monitoring and managing the entire lighting system throughout your facility to make life easier, greener, more productive, and more enjoyable.

### Across the Enterprise

Zūm achieves cutting-edge wireless commercial lighting control and tremendous energy efficiency for every intelligent enterprise. An installer simply connects a single Zūm Wireless Gateway to the Zūm Hub's Control Subnet port to gain control of all Zūm Network Bridges within 150 feet. Each Zūm Network Bridge provides a single point of control for every Zūm occupancy sensor, vacancy sensor, photosensor, keypad, and dimmer or switch within a room or space. Up to 32 devices can connect to a Network Bridge, and up to 200 Network Bridges can connect to a Zūm Hub. A Zūm Hub and a Zūm Gateway synergistically deliver enterprise-wide lighting system central monitoring, management, reporting, and control. With a simple installation and setup process for every device and little to no programming required, Zūm is a revolutionary, easy-touse commercial lighting control system for the intelligent enterprise that values centralized lighting management, scalability, and flexibility in either new or retrofit applications.

### Scalable Lighting Control

The IP-based Zūm platform is engineered from the ground up to deliver a network-grade server appliance capable of faithfully handling everything from daylight harvesting and occupancy sensing in a single room to lighting control and management throughout an entire building. Zūm embodies a distinctively robust, dynamic, and secure platform to elevate your lighting system designs to higher levels of performance and reliability. Zūm provides astonishing processing power and speed with ample memory, rock solid networking and IP control, and a unique modular architecture.

### Modular Architecture


Designed for unparalleled scalability, the Zūm Hub affords high-speed, real-time multi-tasking to seamlessly run multiple programs simultaneously. This exclusive modular architecture lets programmers independently develop and run device-specific lighting programs to optimize energy efficiency and allow for changes to be made to one space without affecting the whole system. Even as your system grows, processing resources can easily be shifted from one Zūm Hub to another without rewriting any code. The end benefit is dramatically simplified upgradability with minimal downtime, whether implementing changes on site or remotely via the network.

### **Dedicated Control Subnet**

A separate LAN port on the Zūm Hub provides a single-point connection to the customer's LAN, requiring just one IP address for the complete control system. The LAN port allows full interconnectivity between devices on the local subnet with other devices, systems, servers, and WAN/Internet connections outside the local subnet.

### BACnet™/IP

Native support for the BACnet/IP communication protocol provides a direct interface to third-party building management systems over Ethernet, simplifying integration with other systems such as HVAC. Using BACnet/IP, each system runs independently with the ability to communicate together on one platform for a truly smart building.





### **GLZUM Specifications**

### **ENVIRONMENTAL**

### Temperature:

41° to 113°F (5° to 45°C)

### Humidity:

10% to 90% rh (non-condensing)

### **BATTERIES**

### Keypads:

CR2032 Lithium Ion (5 years normal use)

### ZUMMESH-OL-PHOTOCELL-BATT:

(2) AAA Lithium Ion (10 years normal use)

### ZUMMESH-PIR-XXX-BATT:

9V Lithium Ion (10 years normal use)

### DEVICES RATED FOR AIR HANDLING (PLENUM) SPACES UL 2043

- > ZUMMESH-JBOX
- > ZUMMESH-NETBRIDGE

### **ZUMMESH WIRELESS**

- > Peer-to-peer mesh network within spaces
- > 2.4Ghz IEEE 802.15.4 (Wi-Fi® friendly)
- > 50 Ft (15 m) range between devices
- > AC powered devices repeat all signals
- > 128-Bit AES encryption
- > Auto-RF channel negotiation
- > 32 Devices per ZUMMESH space

### **ZUMNET WIRELESS**

- > Mesh network connecting spaces
- > 2.4Ghz IEEE 802.15.4 (Wi-Fi friendly)
- > 150 Ft (46 m) range between devices
- > All ZUMNET devices are AC powered and repeat all signals
- > 50 spaces per bridge

### **ENERGY CODE COMPLIANT SOLUTIONS**

ASHRAE 90.1 IECC

TITLE 24

### STANDARDS & CERTIFICATIONS

UL Listed. CE







Products in this system can include:

**ZUMMESH-KPBATT**: Zūm Battery-Powered Wireless Keypad

**ZUMMESH-KP**: Zūm AC-Powered Wireless Keypad

ZUMMESH-OL-PHOTOCELL-BATT: Open Loop Daylight Sensor

ZUMMESH-PIR-OCCUPANCY-BATT: PIR Occupancy Sensor (AUTO-ON, AUTO-OFF) **ZUMMESH-PIR-VACANCY-BATT**: PIR Vacancy Sensor (MANUAL-ON, AUTO-OFF)

**ZUMMESH-JBOX**: Zūm J-Box Load Controller ZUMMESH-5A-SW: Wall-Box Switch, 5A White ZUMMESH-5A-LV: Wall-Box 0-10V Dimmer. 5A White **ZUMMESH-NETBRIDGE**: Zūm Network Bridge

ZUM-FLOOR-HUB: Zūm Floor Hub

ZUMMESH-AVBRIDGE: Zum RS-232/USB AV Bridge

**ZUMNET-GATEWAY**: Zūm Gateway

**ZUMMESH-CCO**: Zūm Contact Closure Output

**ZUMMESH-JBOX-PSU**: Junction Box Network Bridge Power Supply

For technical specifications on all other products in this system, please visit www.crestron.com/zum

For more information or to access digital specification forms for all Crestron SpaceBuilder systems, visit www.crestronspacebuilder.com or call 855-644-7643

GLZUM	SW	LV	DIM	DELV	_JBOX_SW-	JBOX_LV	′5A	JB0X_LV	/16A	DIMU	PL	AKP	_BKP	AKP_BATT-
BKP_	BATT	_CKP_E	BATT	_DKP_BATT-										PS
Date:			Project:	ame:										
Space Number	er(s):													